

CAT. II  

200-250V AC
50Hz, <20mA
Indoor Use Only


HOW TO USE

STEP 1


Before using, check the function of the tester by inserting into a known AC power socket.

STEP 2

Insert the tester into the socket to be tested and follow the lamp indication, refer the test results which is on the chart.



Model no.: MS-CP6(1)



Model no.: MS-CP6(1D)

ELCB Trip Test for model: MS-CP6(1D).
Press the trip switch to trip off the ELCB. Max. <40mA.

NOTES:

- 1) The tester will not detect Neutral and Earth conductor reversed.
- 2) Do not use the tester in a damp and wet socket.
- 3) Do not leave the tester continuous in the socket for long time.
- 4) Max. operating time 5 minutes.